# Promethean

Promethean ActivPanel 9 Quick Start Guide

1 Plug the ActivPanel into a power source

2 Power on the ActivPanel using the Power button on the console.
- If the panel does not initially power on:
  - Check to make sure the rocker switch is turned on. (The rocker switch is located on the back of the panel near the power port)
  - Check to make sure that power supply cord is fully and firmly connected to panel.

3 Connect to the internet
- Use the **Flame** button on the console to access the menu
- Tap **Applications** then tap **Settings**

- Tap on **Network & Internet**, then **Wi-Fi**
- Choose your network and sign in

4 Update the ActivPanel
- Use the **Flame** button on the console to access the menu
- Tap **Applications – Update – Online Update Now**

5 Connect your teacher laptop to switch sources and use content located on your laptop

USB-C   or   HDMI   +   USB touch

Find more resources on
Learn **Promethean**
https://learn.prometheanworld.com/us/

Contact Promethean Support
(678) 368 - 4376